



NEVADA MIRRORED OPEN SHELF WARDROBE ASSEMBLY INSTRUCTIONS




IMPORTANT FOR DOMESTIC USE ONLY


PLEASE READ BEFORE YOU CONTINUE FURTHER

CARE AND MAINTENANCE

- After unpacking this product please keep the original packaging in case it needs to be returned for any reason.
- Please ensure all fittings and parts are present before commencing with assembly.
 - Never drag or push products as this could cause damage to the joints making it inferior.
 - We strongly recommend that you keep children away from your work area.
 - We recommend that you lay a blanket or sheet on the floor to avoid damage to both your floor and the product.
 - Assemble this product as close to its final position as possible.
 - Do not place this product next to a radiator or in direct sunlight.
 - Do not drag or push items across your high gloss furniture as this may cause the surface to scratch
 - Wood is a natural product and may expand if subjected to damp and may shrink or crack if subjected to heat. Therefore it is recommended that room temperature is maintained, with no sudden temperature fluctuations.
 - Make sure any spillage is wiped off immediately.
 - Do not place hot or chilled items directly on to the surface, use a place mat or marking will occur.
 - For general cleaning use a soft cotton or micro fibre cloth, and do not use detergents of any kind.
 - From time to time it may be necessary to tighten fittings, regular inspections should be carried out.
 - Do not place on a wet or damp floor as staining may occur to your floor.



TOOLS REQUIRED


























**PARTS LIST*****Please Note:***

The below parts have all been stamped with the part number to help identify them during assembly

Part Number	Part Description	Quantity	Carton
1	Front Baseboard	1	2/2
2	Back Baseboard	1	2/2
3	Left Side Panel	1	1/2
4	Right Side Panel	1	2/2
5	Small Base Panel	1	2/2
6	Drawer Side	4	2/2
7	Drawer Top Panel	1	2/2
8	Division Panel	1	2/2
9	Shelf	1	2/2
10	External Shelf	2	2/2
11	Back Panel	1	2/2
12	Top Panel	1	2/2
13	Large Top Panel	1	2/2
14	Large Back Panel	1	1/2
15	Small Back Panel	1	2/2
16	Door	1	1/2
17	Left Division Panel	1	1/2
18	Drawer Front	2	2/2
19	Drawer Back Panel	2	2/2
20	Drawer Bottom	2	1/2


FITTINGS LIST






SEC/SH/01/23/DM2



<p>A</p>  <p>Flan Head Screw Ø3,5 x 12mm (6x)</p> <p>1/+</p>	<p>B</p>  <p>Flat Head Screw Ø3,5 X 40mm (17X)</p> <p>2/+</p>	<p>C</p>  <p>Flan Head Screw Ø3,5 x 30mm (2x)</p> <p>1/+</p>	
<p>D</p>  <p>Flat Head Screw Ø4,0 x 14mm (38x)</p> <p>2/+</p>	<p>E</p>  <p>Flan Head Screw Ø4,0 x 20mm (6x)</p> <p>1/+</p>	<p>F</p>  <p>Flat Head Screw Ø6,0 x 8mm (8x)</p> <p>2/+</p>	<p>G</p>  <p>Handle (3x)</p>
<p>H</p>  <p>Glue (3x)</p>	<p>I</p>  <p>Drawer Runners (2x)</p>		<p>J</p>  <p>Hinge Plate (3x)</p>
<p>K</p>  <p>Hinge (3x)</p>	<p>L</p>  <p>Cam Nut 12mm (6x)</p> <p>1/+</p>	<p>M</p>  <p>Cam Bolt (6x)</p> <p>1/+</p>	<p>N</p>  <p>Dowel Ø6,0 x 30mm (56x)</p> <p>2/+</p>
<p>O</p>  <p>Back Panel Bracket (5x)</p> <p>1/+</p>	<p>P</p>  <p>Hanging Rail Support (2x)</p>	<p>Q</p>  <p>Metalic Hook (2x)</p>	<p>R</p>  <p>Metalic Bracket (2x)</p>
<p>S</p>  <p>Plastic Foot (6x)</p> <p>1/+</p>	<p>T</p>  <p>Nail 10 x 10 (80x)</p> <p>5/+</p>	<p>U</p>  <p>Hole Plugs (30x)</p> <p>2/+</p>	<p>V</p>  <p>Washer (4x)</p> <p>1/+</p>
<p>W</p>  <p>Hanging Rail (1x)</p>		<p>X</p>  <p>Strap 200mm (2x)</p>	<p>Y</p>  <p>Flat Head Screw Ø4,0 X 45mm (26X)</p> <p>2/+</p>



TIPS FOR FITTINGS CAM-LOCKS


WHEN FITTING CAM NUT, ENSURE STARTING POSITION IS CORRECT BEFORE YOU INSERT CONNECTING CAM BOLT TURN CLOCKWISE UNTIL SECURE



  **CORRECT**


  **WRONG**



Cam bolt head needs to be in centre

CAMBOLT

Tighten until shoulder is flush with panel. Do not overtighten or undertighten (see example beside)




STEP 1

PARTS REQUIRED

3 - LEFT SIDE PANEL x1




HARDWARE REQUIRED

D  08
Ø4,0 x 14mm

J  03

P  01

TOOLS REQUIRED




STEP 2

PARTS REQUIRED


3 - LEFT SIDE PANEL x1

HARDWARE REQUIRED




H  01
Glue

N  02
Ø6,0 x 30mm

S  02

T  02

TOOLS REQUIRED




STEP 3


PARTS REQUIRED

17 - LEFT DIVISION PANEL x1

HARDWARE REQUIRED




D  02
Ø4,0 x 14mm

H  01
Glue

N  04
Ø6,0 x 30mm

P  01

TOOLS REQUIRED





STEP 4

PARTS REQUIRED





17 - LEFT DIVISION PANEL x1

HARDWARE REQUIRED

F  04
Ø6,0 x 8mm

I  02
Left

TOOLS REQUIRED





STEP 5


PARTS REQUIRED


4 - RIGHT SIDE PANEL x1

HARDWARE REQUIRED


F  04
Ø6,0 x 8mm

H  01




I  Right 02

N  02
Ø6,0 x 30mm


S  02

T  02

TOOLS REQUIRED




Detail 6



PLEASE NOTE
PRE-DRILLED
HOLES.



Detail 1



Detail 4


STEP 6


PARTS REQUIRED

5 - SMALL BASE PANEL x1


8 - DIVISION PANEL x1

HARDWARE REQUIRED

H  01

N  06
Ø6,0 x 30mm

TOOLS REQUIRED



Detail 1

STEP 7


PARTS REQUIRED


1 - FRONT BASEBOARD x1

2 - BACK BASEBOARD x1


9 - SHELF x1

HARDWARE REQUIRED



H  01

N  Ø6,0 x 30mm 12

S  02

T  02

TOOLS REQUIRED



STEP 8

PARTS REQUIRED


10 - EXTERNAL SHELF x2

11 - BACK PANEL x1

HARDWARE REQUIRED



D  Ø4,0 x 14mm 02

H  01

N  Ø6,0 x 30mm 12

Q  02

TOOLS REQUIRED




STEP 9


PARTS REQUIRED

7 - DRAWER TOP PANEL x1




HARDWARE REQUIRED

H  01


N  Ø6,0 x 30mm 02

M  02

TOOLS REQUIRED



Detail 9



Detail 1

STEP 10


PARTS REQUIRED


5 - SMALL BASE PANEL x1

9 - SHELF x1




17 - LEFT DIVISION PANEL x1

HARDWARE REQUIRED


H  01

Y  Ø4,0 X 45MM 04

TOOLS REQUIRED



Detail 13




Detail 1

STEP 11


PARTS REQUIRED

3 - LEFT SIDE PANEL x1






HARDWARE REQUIRED


H  01

Y  04
Ø4.0 X 45MM

TOOLS REQUIRED



Detail 1




Detail 13

STEP 12


PARTS REQUIRED

7 - DRAWER TOP PANEL x1






HARDWARE REQUIRED


H  01

Y  02
Ø4.0 X 45MM

TOOLS REQUIRED



Detail 1




Detail 13

STEP 13

PARTS REQUIRED

4 - RIGHT SIDE PANEL x1






HARDWARE REQUIRED


H  01

L  02


TOOLS REQUIRED



Detail 1



Detail 21



STEP 14


PARTS REQUIRED

1 - FRONT BASEBOARD x1





2 - BACK BASEBOARD x1

HARDWARE REQUIRED


H  01

Y  06
Ø4.0 X 45MM

TOOLS REQUIRED



Detail 1




Detail 13



STEP 15

PARTS REQUIRED




10 - EXTERNAL SHELF x2




HARDWARE REQUIRED

- | | | |
|---|---|----|
| H |  | 01 |
| Y |  | 02 |
- Ø4,0 X 45MM

TOOLS REQUIRED



Detail 1




Detail 13

STEP 16


PARTS REQUIRED

8 - DIVISION PANEL x1






HARDWARE REQUIRED


H  01

Y  04
Ø4.0 X 45MM

TOOLS REQUIRED



Detail 1




Detail 13


STEP 17

PARTS REQUIRED





11 - BACK PANEL x1

HARDWARE REQUIRED


B  Ø3,5 X 40mm 06

H  Glue 01


TOOLS REQUIRED



Detail 1



Detail 13




*You should assemble this step with two people

STEP 18

PARTS REQUIRED





12 - TOP PANEL x1

HARDWARE REQUIRED


B  04
Ø3,5 X 40mm

H  01
Glue

TOOLS REQUIRED



Detail 1




Detail 13

STEP 19

PARTS REQUIRED





13 - LARGE TOP PANEL x1

HARDWARE REQUIRED


B  04
Ø3,5 X 40mm

H  01
Glue

TOOLS REQUIRED




Detail 1



Detail 13

STEP 20


PARTS REQUIRED





HARDWARE REQUIRED



TOOLS REQUIRED



Detail 30



Detail 30


STEP 21


PARTS REQUIRED

14 - LARGE BACK PANEL x1



15 - SMALL BACK PANEL x1

HARDWARE REQUIRED


O  05

T  54




TOOLS REQUIRED




*Part 14 must be lined up on the edge of part 12



* For your future reference Order Number should be here.



Detail 15




Detail 17

PARTS REQUIRED


14 - LARGE BACK PANEL x1


15 - SMALL BACK PANEL x1








HARDWARE REQUIRED

A  06
Ø3,5 x 12mm


B  03
Ø3,5 X 40mm

T  02
10 x 10


TOOLS REQUIRED



Detail 15




Detail 16



Detail 13

STEP 23


PARTS REQUIRED




HARDWARE REQUIRED



TOOLS REQUIRED



Detail 19



STEP 24




PARTS REQUIRED

6 - DRAWER SIDE x4



18 - DRAWER FRONT x2

19 - DRAWER BACK PANEL x2


HARDWARE REQUIRED




TOOLS REQUIRED



Detail 1



Detail 9



STEP 25


PARTS REQUIRED

6 - DRAWER SIDE x4



19 - DRAWER BACK PANEL x2

HARDWARE REQUIRED

H  01

Y  Ø4,0 X 45MM 04


TOOLS REQUIRED




STEP 26

PARTS REQUIRED



18 - DRAWER FRONT x2



HARDWARE REQUIRED


H  01

TOOLS REQUIRED



STEP 27





PARTS REQUIRED



HARDWARE REQUIRED



TOOLS REQUIRED




Detail 21


STEP 28

PARTS REQUIRED










20 - DRAWER BOTTOM x2



HARDWARE REQUIRED




TOOLS REQUIRED




Detail 22

STEP 29





PARTS REQUIRED



HARDWARE REQUIRED




TOOLS REQUIRED






STEP 30




PARTS REQUIRED



HARDWARE REQUIRED



TOOLS REQUIRED




STEP 31

PARTS REQUIRED




16 - DOOR x1

HARDWARE REQUIRED

D  06
Ø4,0 x 14mm

K  03


TOOLS REQUIRED



STEP 32

PARTS REQUIRED





16 - DOOR x1



HARDWARE REQUIRED




U  22

TOOLS REQUIRED







STEP 33

PARTS REQUIRED




TOOLS REQUIRED




Detail 25

STEP 34




PARTS REQUIRED



HARDWARE REQUIRED




TOOLS REQUIRED




Detail 23



Height Adjustment



Internal Adjustment



Depth Adjustment



WARNING

Serious or fatal injuries can occur from furniture tipping over. To prevent the furniture from tipping over we recommend that it is permanently fixed to the wall.

Wall fixings are not supplied with this product as different wall materials require different types of fixing devices.

Please make sure you use fixings suitable for the walls in your home.

