


NEVADA 6 DRAWER CHEST ASSEMBLY INSTRUCTIONS 3D EFFECT GREY



IMPORTANT

FOR DOMESTIC USE ONLY


PLEASE READ BEFORE YOU CONTINUE FURTHER

CARE AND MAINTENANCE

After unpacking this product please keep the original packaging in case it needs to be returned for any reason.

- Please ensure all fittings and parts are present before commencing with assembly.
- Never drag or push products as this could cause damage to the joints making it inferior.
- We strongly recommend that you keep children away from your work area.
- We recommend that you lay a blanket or sheet on the floor to avoid damage to both your floor and the product.
- Assemble this product as close to its final position as possible.
- Do not place this product next to a radiator or in direct sunlight.
- Do not drag or push items across your high gloss furniture as this may cause the surface to scratch
- Wood is a natural product and may expand if subjected to damp and may shrink or crack if subjected to heat. Therefore it is recommended that room temperature is maintained, with no sudden temperature fluctuations.
- Make sure any spillage is wiped off immediately.
- Do not place hot or chilled items directly on to the surface, use a place mat or marking will occur.
- For general cleaning use a soft cotton or micro fibre cloth, and do not use detergents of any kind.
- From time to time it may be necessary to tighten fittings, regular inspections should be carried out.
- Do not place on a wet or damp floor as staining may occur to your floor.

*For your future reference Order Number should be here























PARTS LIST

Please Note:
The below parts have all been stamped with the part number/color to help identify them during assembly.


Part Numer/Color	Part Code	Part Description	Quantity	Carton
1	S100-102-150-SP1-01	Left SidePanel - RED	1	1/2
2	S100-102-150-SP1-02	Back Baseboard - BLACK	2	1/2
3	S100-102-150-SP1-03	Front Baseboard - GREEN	2	1/2
4	S100-102-150-SP1-04	Crossbar - YELLOW	2	1/2
5	S100-102-150-SP1-05	Division Panel - GREEN	1	1/2
6	S100-102-150-SP1-06	Right Side Panel - BLUE	1	1/2
7	S100-102-150-SP1-07	Top Panel - BLACK	1	2/2
8	S100-102-150-SP1-08	Back Panel	2	2/2
9	S100-102-150-SP1-09	Drawer Back Panel - YELLOW	6	1/2
10	S100-102-150-SP1-10	Drawer Side - BLUE	12	2/2
11	S100-102-150-SP1-11	Drawer Front	6	2/2
12	S100-102-150-SP1-12	Drawer Botom	6	2/2

FITTINGS LIST


<p>A</p>  <p>Flat Head Screw Ø4,0 x 14mm (36x)</p> <p>+/2</p>	<p>B</p>  <p>Flat Head Screw Ø6,0 x 8,0mm (24x)</p> <p>+/2</p>	<p>C</p>  <p>Flan Head Screw Ø4,0 x 22mm (12x)</p> <p>+/2</p>	<p>D</p>  <p>Flan Head Screw Ø3,5 x 30mm (2x)</p> <p>+/1</p>
<p>E</p>  <p>Flat Head Screw Ø4,0x 50mm (12x)</p> <p>+/2</p>	<p>F</p>  <p>Dowel Ø6,0 x 30mm (66x)</p> <p>+/2</p>	<p>G</p>  <p>Dowel Ø6,0 x 50mm (6x)</p> <p>+/1</p>	
<p>H</p>  <p>Nail 10 x 10 (116x)</p> <p>+/2</p>	<p>I</p>  <p>Back Panel Strip (1x)</p>	<p>J</p>  <p>Cam Bolt (24x)</p> <p>+/2</p>	<p>K</p>  <p>Double Cam Bolt (3x)</p> <p>+/1</p>
<p>L</p>  <p>Cam Nut Ø15mm (18x)</p> <p>+/2</p>	<p>M</p>  <p>Cam Nut Ø12mm (12x)</p> <p>+/2</p>	<p>N</p>  <p>Plastic Foot (6x)</p> <p>+/1</p>	<p>O</p>  <p>Hole Plugs (12x)</p> <p>+/2</p>
<p>P</p>  <p>Glue (2x)</p>	<p>Q</p>  <p>Strap (2x)</p>	<p>R</p>  <p>Washer (4x)</p> <p>+/1</p>	<p>S</p>  <p>Handle (6x)</p>
<p>T</p>  <p>Drawer Runners (6x)</p>			

TIPS FOR FITTINGS CAM-LOCKS

WHEN FITTING CAM NUT. ENSURE STARTING POSITION IS CORRECT BEFORE YOU INSERT CONNECTING CAM BOLT TURN CLOCKWISE UNTIL SECURE




✓




↑

CORRECT




✗



↑


WRONG



Cam bolt head needs to be in centre

CAMBOLT

Tighten until shoulder in flush with panel. Do not overtighten or undertighten (see example beside)



STEP 1


PARTS REQUIRED


2 - BACK BASEBOARD (BLACK) x2


3 - FRONT BASEBOARD (GREEN)x2

4 - CROSSBAR (YELLOW) x2



HARDWARE REQUIRED

F  12
Ø6,0 x 30mm

G  06
Ø6,0 x 50mm

P  01
Glue

TOOLS REQUIRED




STEP 2



PARTS REQUIRED

7 - TOP PANEL (BLACK) x1

HARDWARE REQUIRED

J  06
Cam Bolt

TOOLS REQUIRED




STEP 3

PARTS REQUIRED





6 - RIGHT SIDE PANEL (BLUE)x1

HARDWARE REQUIRED

B  06
Ø 6,0 x 8,0mm

T  03
Right

TOOLS REQUIRED





STEP 4

PARTS REQUIRED





1 - LEFT SIDE PANEL (RED) x1

HARDWARE REQUIRED

B  06
Ø 6,0 x 8,0mm

T  03
Left

TOOLS REQUIRED




STEP 5

PARTS REQUIRED





5 - DIVISION PANEL (GREEN) x1

HARDWARE REQUIRED

B  06
Ø 6,0 x 8,0mm

T  03
Left

TOOLS REQUIRED





STEP 6

PARTS REQUIRED





5 - DIVISION PANEL (GREEN) x1

HARDWARE REQUIRED

B  06
Ø 6,0 x 8,0mm

T  03
Right

TOOLS REQUIRED




STEP 7

PARTS REQUIRED

5 - DIVISION PANEL (GREEN) x1

HARDWARE REQUIRED



F  02
Ø6,0 x 30mm

H  02


N  02

P  01

TOOLS REQUIRED



Detail 1



Detail 6


STEP 8

PARTS REQUIRED


1 - LEFT SIDE PANEL (RED) x1

6 - RIGHT SIDE PANEL (BLUE) x1


HARDWARE REQUIRED

F  04
Ø6,0 x 30mm



H  04

J  06
Cam Bolt


N  04

P  01


TOOLS REQUIRED




Detail 1



Detail 6



Detail 3



STEP 9

PARTS REQUIRED

2 - BACK BASEBOARD (BLACK) x2


3 - FRONT BASEBOARD (GREEN) x2

4 - CROSSBAR (YELLOW) x2

5 - DIVISION PANEL (GREEN) x1






HARDWARE REQUIRED

K  03

L  06

P  01

TOOLS REQUIRED



Detail 1


Detail 8

STEP 10

PARTS REQUIRED


1 - LEFT SIDE PANEL (RED) x1

6 - RIGHT SIDE PANEL (BLUE) x1








HARDWARE REQUIRED

L  06

P  01

TOOLS REQUIRED




Detail 1

Detail 9

STEP 11


PARTS REQUIRED

7 - TOP PANEL (BLACK) x1






HARDWARE REQUIRED


L  06

P  01


TOOLS REQUIRED



Detail 1



Detail 10




Cam bolt head needs to be in centre


STEP 12

PARTS REQUIRED

8 - BACK PANEL x2





HARDWARE REQUIRED


H  46
10 x 10

I  01

TOOLS REQUIRED




* For your future reference
Order Number should be here




Detail 11

STEP 13


PARTS REQUIRED





HARDWARE REQUIRED



TOOLS REQUIRED



* For your future reference
Order Number should be here




Detail 12

STEP 14




PARTS REQUIRED

11 - DRAWER FRONT x6

HARDWARE REQUIRED



TOOLS REQUIRED



Detail 3

STEP 15

PARTS REQUIRED

9 - DRAWER BACK PANEL (YELLOW)x6




10 - DRAWER SIDE (BLUE) x12

HARDWARE REQUIRED

F  48
Ø6,0 x 30mm

P  01
Glue

TOOLS REQUIRED




STEP 16

PARTS REQUIRED




9 - DRAWER BACK PANEL (YELLOW)x6

10 - DRAWER SIDE (BLUE) x12

HARDWARE REQUIRED

E  12
Ø4,0 x 50mm


TOOLS REQUIRED



STEP 17

PARTS REQUIRED


11 - DRAWER FRONT x6








HARDWARE REQUIRED

M  12

O  12

P  01


TOOLS REQUIRED




STEP 18

PARTS REQUIRED









12 - DRAWER BOTTOM x6



HARDWARE REQUIRED

H  10 x 10 24


TOOLS REQUIRED



Detail 15

STEP 19




PARTS REQUIRED



HARDWARE REQUIRED




TOOLS REQUIRED




STEP 20





PARTS REQUIRED



HARDWARE REQUIRED




TOOLS REQUIRED




STEP 21



PARTS REQUIRED




HARDWARE REQUIRED



TOOLS REQUIRED





Detail 16




STEP 22

PARTS REQUIRED




 See the last page




STEP 23


PARTS REQUIRED



HARDWARE REQUIRED




TOOLS REQUIRED



Detail 17

Detail 17

Detail 17



Drawer Adjustment

Drawer Lock





Detail 17

WARNING


Serious or fatal injuries can occur from furniture tipping over. To prevent the furniture from tipping over we recommend that it is permanently fixed to the wall.

Wall fixings are not supplied with this product as different wall materials require different types of fixing devices.


Please make sure you use fixings suitable for the walls in your home.



D Flan Head Screw
Ø3,5 x 30mm (2x)



R Washer (4x)



Q Strap (2x)