


# CODY 2 DOOR 1 DRAWER WARDROBE ASSEMBLY INSTRUCTIONS WHITE/PINE EFFECT




## **IMPORTANT FOR DOMESTIC USE ONLY**

**PLEASE READ BEFORE YOU CONTINUE FURTHER**

## **CARE AND MAINTENANCE**

After unpacking this product please keep the original packaging in case it needs to be returned for any reason.

- Please ensure all fittings and parts are present before commencing with assembly.
- Never drag or push products as this could cause damage to the joints making it inferior.
- We strongly recommend that you keep children away from your work area.
- We recommend that you lay a blanket or sheet on the floor to avoid damage to both your floor and the product.
- Assemble this product as close to its final position as possible.
- Do not place this product next to a radiator or in direct sunlight.
- Do not drag or push items across your high gloss furniture as this may cause the surface to scratch
- Wood is a natural product and may expand if subjected to damp and may shrink or crack if subjected to heat. Therefore it is recommended that room temperature is maintained, with no sudden temperature fluctuations.
- Make sure any spillage is wiped off immediately.
- Do not place hot or chilled items directly on to the surface, use a place mat or marking will occur.
- For general cleaning use a soft cotton or micro fibre cloth, and do not use detergents of any kind.
- From time to time it may be necessary to tighten fittings, regular inspections should be carried out.
- Do not place on a wet or damp floor as staining may occur to your floor.



























**PARTS LIST**

**Please Note:**  
The below parts have all been stamped with the part number to help identify them during assembly.


Part Number	Part Code	Part Description	Quantity	Carton
1	S100-101-186-DV1-01	Left Leg	2	2/2
2	S100-101-186-DV1-02	Leg Support Left & Right	2	2/2
3	S100-101-186-DV1-03	Right Leg	2	2/2
4	S100-101-186-DV1-04	Leg Support Front & Back	2	2/2
5	S100-101-186-DV1-05	Base Panel	1	2/2
6	S100-101-186-DV1-06	Left Side Panel	1	1/2
7	S100-101-186-DV1-07	Shelf	1	2/2
8	S100-101-186-DV1-08	Right Side Panel	1	1/2
9	S100-101-186-DV1-09	Top Panel	1	2/2
10	S100-101-186-DV1-10	Back Panel	2	1/2
11	S100-101-186-DV1-11	Drawer Sides	2	2/2
12	S100-101-186-DV1-12	Drawer Back	1	2/2
13	S100-101-186-DV1-13	Drawer Base	1	2/2
14	S100-101-186-DV1-14	Drawer Base Support	1	2/2
15	S100-101-186-DV1-15	Drawer Front	1	2/2
16	S100-101-186-DV1-16	Left Door	1	1/2
17	S100-101-186-DV1-17	Right Door	1	1/2

## FITTINGS LIST


<p><b>A</b></p>  <p style="text-align: center;">Glue (3x)</p>	<p><b>B</b></p>  <p style="text-align: center;">2/+ Dowel Ø6,0 x 30mm (26x)</p>	<p><b>C</b></p>  <p style="text-align: center;">Slide 450mm (1x)</p>	<p><b>D</b></p>  <p style="text-align: center;">1/+ Flat Head Screw Ø4,0 x 40mm (8x)</p>
<p><b>E</b></p>  <p style="text-align: center;">5/+ Nail 10 x 10 (45x)</p>	<p><b>F</b></p>  <p style="text-align: center;">1/+ Cam Nut 12mm (6x)</p>	<p><b>G</b></p>  <p style="text-align: center;">1/+ Cam Bolt (22x)</p>	<p><b>H</b></p>  <p style="text-align: center;">1/+ Screw Ø 6x8 (4x)</p>
<p><b>I</b></p>  <p style="text-align: center;">1/+ Flat Head Screw Ø3,0 x 14mm (8x)</p>	<p><b>J</b></p>  <p style="text-align: center;">1/+ Hole Plugs (6x)</p>	<p><b>K</b></p>  <p style="text-align: center;">(1X) Washer 02      Anti-tip strap 01</p>	
<p><b>L</b></p>  <p style="text-align: center;">1/+ Flat Head Screw Ø4,0 x 30mm (3x)</p>	<p><b>M</b></p>  <p style="text-align: center;">2/+ Flat Head Screw Ø4,0 x 14mm (24x)</p>	<p><b>N</b></p>  <p style="text-align: center;">1/+ Dowel Ø8,0 x 30mm (8x)</p>	<p><b>O</b></p>  <p style="text-align: center;">1/+ Cam Nut 15mm (16x)</p>
<p><b>P</b></p>  <p style="text-align: center;">1/+ Flat Head Screw Ø3,5 x 25mm (2x)</p>	<p><b>Q</b></p>  <p style="text-align: center;">Hanging Rail Support (2x)</p>	<p><b>R</b></p>  <p style="text-align: center;">Hinge (6x)</p>	<p><b>S</b></p>  <p style="text-align: center;">1/+ Flat Head Screw Ø3,5 x 12mm (4x)</p>
<p><b>T</b></p>  <p style="text-align: center;">Hinge Plate (6x)</p>	<p><b>U</b></p>  <p style="text-align: center;">Door Stop (2x)</p>	<p><b>V</b></p>  <p style="text-align: center;">Hanging Rail 760mm (1x)</p>	
<p><b>W</b></p>  <p style="text-align: center;">Plastic profile 1596 mm (1x)</p>		<p><b>Y</b></p>  <p style="text-align: center;">Handle(3x)</p>	

### TIPS FOR FITTINGS CAM-LOCKS


WHEN FITTING CAM NUT. ENSURE STARTING POSITION IS CORRECT BEFORE YOU INSERT CONNECTING CAM BOLT TURN CLOCKWISE UNTIL SECURE



↑  
**CORRECT**




↑  
**WRONG**



**Cam bolt head needs to be in centre**

**CAMBOLT**

Tighten until shoulder in flush with panel. Do not overtighten or undertighten (see example beside)



# STEP 1

## PARTS REQUIRED




1 - LEFT LEG x2

3 - RIGHT LEG x2

## HARDWARE REQUIRED

G  08

## TOOLS REQUIRED




# STEP 2


## PARTS REQUIRED

2- LEG SUPPORT LEFT+RIGHT x2

4- LEG SUPPORT FRONT+BACK x2




## HARDWARE REQUIRED

A  01

B  Ø6 x 30mm 04

N  Ø8 x 30mm 08

## TOOLS REQUIRED









# STEP 3






## PARTS REQUIRED

7- SHELF x1

## HARDWARE REQUIRED

- A  01
- B  04  
Ø6 x 30mm
- S  02  
Ø3,5 x 12mm
- U  01

## TOOLS REQUIRED






# STEP 4







## PARTS REQUIRED

9 - TOP PANEL x1

## HARDWARE REQUIRED

- G  04
- S  02  
Ø3,5 x 12mm
- U  01

## TOOLS REQUIRED





# STEP 5


### PARTS REQUIRED

6- LEFT SIDE PANEL x1






### HARDWARE REQUIRED

A  01

B  Ø6 x 30mm 04

G  02

### TOOLS REQUIRED




# STEP 6

### PARTS REQUIRED

6- LEFT SIDE PANEL x1

### HARDWARE REQUIRED






I  Ø3,0 x 14mm 02

M  Ø4,0 x 14mm 06

Q  01

T  03

### TOOLS REQUIRED



# STEP 7

## PARTS REQUIRED





6- LEFT SIDE PANEL x1

## HARDWARE REQUIRED

C  01  
450mm

H  02  
Ø6 x 8mm

## TOOLS REQUIRED





# STEP 8


## PARTS REQUIRED

8- RIGHT SIDE PANEL x1







## HARDWARE REQUIRED

A  01

B  04  
Ø6 x 30mm

G  02

## TOOLS REQUIRED




# STEP 9

## PARTS REQUIRED

8- RIGHT SIDE PANEL x1

## HARDWARE REQUIRED




I  02  
Ø3.0 x 14mm

M  06  
Ø4.0 x 14mm


Q  01

T  03


## TOOLS REQUIRED



Detail 5



Detail 5



Detail 6

# STEP 10

## PARTS REQUIRED





8- RIGHT SIDE PANEL x1

## HARDWARE REQUIRED

C  01  
450mm Right

H  02  
Ø6 x 8mm

## TOOLS REQUIRED





Detail 7

# STEP 11




## PARTS REQUIRED

1- LEFT FOOT	x2
3- RIGHT FOOT	x2
4- FRONT AND REAR FOOTER	x2


## HARDWARE REQUIRED

A		01
O		04


## TOOLS REQUIRED



Detail 9



Detail 8




Cam bolt head needs to be in centre



# STEP 12

## PARTS REQUIRED




2- SIDE FOOTER	x2
----------------	----




## HARDWARE REQUIRED

A		01
O		02


## TOOLS REQUIRED



Detail 9




Detail 8




Cam bolt head needs to be in centre

# STEP 13




## PARTS REQUIRED




## HARDWARE REQUIRED




## TOOLS REQUIRED



Detail 9




Detail 8





# STEP 14




## PARTS REQUIRED




## HARDWARE REQUIRED



## TOOLS REQUIRED




Detail 9




Detail 10

# STEP 15




**PARTS REQUIRED**



**HARDWARE REQUIRED**



**TOOLS REQUIRED**




# STEP 16




**PARTS REQUIRED**




**HARDWARE REQUIRED**




**TOOLS REQUIRED**



Detail 9




Detail 11



# STEP 17

## PARTS REQUIRED

8- RIGHT SIDE PANEL x1






## HARDWARE REQUIRED


A  01

F  Ø12mm 02


## TOOLS REQUIRED



Detail 9




Detail 11



# STEP 18

## PARTS REQUIRED






## HARDWARE REQUIRED


A  01

O  04


## TOOLS REQUIRED



Detail 9



Detail 8






# STEP 19

**PARTS REQUIRED**




9- TOP PANEL x1




**HARDWARE REQUIRED**

A		01
O		04
J		04


**TOOLS REQUIRED**



Detail 9



Detail 8




Cam bolt head needs to be in centre

# STEP 20

**PARTS REQUIRED**




10- BACK PANEL x2




**HARDWARE REQUIRED**

E		32
W		01

**TOOLS REQUIRED**




Detail 12




Detail 12

# STEP 21




**PARTS REQUIRED**



**HARDWARE REQUIRED**



**TOOLS REQUIRED**





Detail 12

# STEP 22




**PARTS REQUIRED**

- 11- DRAWER SIDES x2
- 12- DRAWER BACK x1
- 14- DRAWER BASE SUPPORT x2

**HARDWARE REQUIRED**



**TOOLS REQUIRED**



Detail 1

# STEP 23




## PARTS REQUIRED

15- DRAWER FRONT x1

## HARDWARE REQUIRED

G  02

## TOOLS REQUIRED




# STEP 24

## PARTS REQUIRED




11- DRAWER SIDES x2

12- DRAWER BACK x1

## HARDWARE REQUIRED

D  Ø4,0 x 40mm 02


## TOOLS REQUIRED



# STEP 25

**PARTS REQUIRED**

15 - DRAWER FRONT x1






**HARDWARE REQUIRED**

A 01


F Ø12mm 02

J 02


**TOOLS REQUIRED**



Detail 9



Detail 15




# STEP 26

**PARTS REQUIRED**

13 - DRAWER BASE x1

14 - DRAWER BASE SUPPORT x1






**HARDWARE REQUIRED**


A 01

E 08



**TOOLS REQUIRED**



Detail 9




Detail 16





# STEP 27



## PARTS REQUIRED



## HARDWARE REQUIRED




## TOOLS REQUIRED





# STEP 28




## PARTS REQUIRED



## HARDWARE REQUIRED




## TOOLS REQUIRED



Detail 19


# STEP 29

PARTS REQUIRED




HARDWARE REQUIRED

TOOLS REQUIRED




# STEP 30




PARTS REQUIRED



HARDWARE REQUIRED



TOOLS REQUIRED



Detail 20


# STEP 31

## PARTS REQUIRED

16- LEFT DOOR x1




17- RIGHT DOOR x1

## HARDWARE REQUIRED

M  12  
Ø4,0 x 14mm

R  06

## TOOLS REQUIRED




Detail 21

# STEP 32


## PARTS REQUIRED


16- LEFT DOOR x1

17- RIGHT DOOR x1







## HARDWARE REQUIRED


L  02  
Ø4,0 x 30mm

Y  02

## TOOLS REQUIRED




Detail 22




Detail 23

# STEP 33






## PARTS REQUIRED



## HARDWARE REQUIRED

K  01

## TOOLS REQUIRED



## **WARNING**


**Serious or fatal injuries can occur from furniture tipping over. To prevent the furniture from tipping over we recommend that it is permanently fixed to the wall.**

Wall fixings are not supplied with this product as different wall materials require different types of fixing devices. Please make sure you use fixings suitable for the walls in your home.



# CODY 2+2 DRAWER CHEST ASSEMBLY INSTRUCTIONS WHITE/PINE EFFECT

XXXXXX



## **IMPORTANT FOR DOMESTIC USE ONLY PLEASE READ BEFORE YOU CONTINUE FURTHER CARE AND MAINTENANCE**

After unpacking this product please keep the original packaging in case it needs to be returned for any reason.



- Please ensure all fittings and parts are present before commencing with assembly.
- Never drag or push products as this could cause damage to the joints making it inferior.
- We strongly recommend that you keep children away from your work area.
- We recommend that you lay a blanket or sheet on the floor to avoid damage to both your floor and the product.
- Assemble this product as close to its final position as possible.
- Do not place this product next to a radiator or in direct sunlight.
- Do not drag or push items across your high gloss furniture as this may cause the surface to scratch
- Wood is a natural product and may expand if subjected to damp and may shrink or crack if subjected to heat. Therefore it is recommended that room temperature is maintained, with no sudden temperature fluctuations.
- Make sure any spillage is wiped off immediately.
- Do not place hot or chilled items directly on to the surface, use a place mat or marking will occur.
- For general cleaning use a soft cotton or micro fibre cloth, and do not use detergents of any kind.
- From time to time it may be necessary to tighten fittings, regular inspections should be carried out.
- Do not place on a wet or damp floor as staining may occur to your floor.



\* Use of power tools to assemble this product will invalidate any claim and could damage this product making it unsafe!!!  
\* Please assemble on a clean soft surface to avoid damage.



\* Please check contents and read the instructions before commencing assembly.  
\* Assemble this product following the enclosed instructions carefully.  
\* Please take care to avoid damaging parts during assembly.






















## PART LIST

### Please Note:


The below parts have all been stamped with the part number/color to help identify them during assembly.

Part Number	Part Code	Part Description	Quantity	Carton
1	S100-102-162-DV1-01	Left Leg	2	1/1
2	S100-102-162-DV1-02	Leg Support Left & Right	2	1/1
3	S100-102-162-DV1-03	Right Leg	2	1/1
4	S100-102-162-DV1-04	Leg Support Front & Back	2	1/1
5	S100-102-162-DV1-05	Base Panel	1	1/1
6	S100-102-162-DV1-06	Left Side Panel	1	1/1
7	S100-102-162-DV1-07	Centre Support	1	1/1
8	S100-102-162-DV1-08	Right Side panel	1	1/1
9	S100-102-162-DV1-09	Dividing Panel	1	1/1
10	S100-102-162-DV1-10	Top Panel	1	1/1
11	S100-102-162-DV1-11	Back Panel	2	1/1
12	S100-102-162-DV1-12	Drawer Back (Large)	1	1/1
13	S100-102-162-DV1-13	Drawer Sides	6	1/1
14	S100-102-162-DV1-14	Drawer Back (Small)	2	1/1
15	S100-102-162-DV1-15	Drawer Front Pine (Large)	1	1/1
16	S100-102-162-DV1-16	Drawer Base	2	1/1
17	S100-102-162-DV1-17	Drawer Front (Left)	1	1/1
18	S100-102-162-DV1-18	Drawer Front (Right)	1	1/1
19	S100-102-162-DV1-19	Drawer Back (Medium)	1	1/1
20	S100-102-162-DV1-20	Drawer Base(Large)	2	1/1
21	S100-102-162-DV1-21	Centre Drawer Front	1	1/1
22	S100-102-162-DV1-22	Drawer Sides (Large)	2	1/1
23	S100-102-162-DV1-23	Drawer Base Support	2	1/1



## FITTINGS LIST

<p><b>A</b></p>  <p style="text-align: center;">Glue (3x)</p>	<p><b>B</b></p>  <p style="text-align: center;">2/+ Dowel Ø6,0 x 30mm (53x)</p>	<p><b>C</b></p>  <p style="text-align: center;">Slide 350mm (4x)</p>	<p><b>D</b></p>  <p style="text-align: center;">1/+ Flat Head Screw Ø4,0 x 40mm (14x)</p>
<p><b>E</b></p>  <p style="text-align: center;">5/+ Nail 10 x 10 (52x)</p>	<p><b>F</b></p>  <p style="text-align: center;">1/+ Cam Nut 12mm (8x)</p>	<p><b>G</b></p>  <p style="text-align: center;">1/+ Cam Bolt (28x)</p>	<p><b>H</b></p>  <p style="text-align: center;">1/+ Screw Ø 6x8 (16x)</p>
<p><b>I</b></p>  <p style="text-align: center;">1/+ Flat Head Screw Ø3,0 x 14mm (16x)</p>	<p><b>J</b></p>  <p style="text-align: center;">2/+ Hole Plugs (8x)</p>	<p><b>K</b></p>  <p style="text-align: center;">Washer 02 (1X) Ø3,5x25 01 Anti-tip strap 01</p>	
<p><b>L</b></p>  <p style="text-align: center;">1/+ Flan Head Screw Ø4,0 x 30mm (4x)</p>	<p><b>M</b></p>  <p style="text-align: center;">2/+ Dowel Ø8,0 x 30mm (8x)</p>	<p><b>N</b></p>  <p style="text-align: center;">1/+ Cam Nut 15mm (20x)</p>	<p><b>O</b></p>  <p style="text-align: center;">Handle(4x)</p>
<p><b>P</b></p>  <p style="text-align: center;">1/+ Flat Head Screw Ø3,5 x 25mm (4x)</p>	<p><b>Q</b></p>  <p style="text-align: center;">1/+ Back Panel Bracket (4x)</p>	<p><b>R</b></p>  <p style="text-align: center;">Flat Head Screw Ø4,0 x 50mm (1x)</p>	<p><b>S</b></p>  <p style="text-align: center;">Plastic profile 456mm (1x)</p>

## TOOLS REQUIRED




## TIPS FOR FITTINGS CAM-LOCKS



### **CAMBOLT**

Tighten until shoulder in flush with panel. Do not overtighten or undertighten (see example beside)



# STEP 1




## PARTS REQUIRED

1 - LEFT LEG	x2
3 - RIGHT LEG	x2

## HARDWARE REQUIRED

G		08
---	---	----

## TOOLS REQUIRED





# STEP 2

## PARTS REQUIRED

2- LEG SUPPORT LEFT+RIGHT	x2
4- LEG SUPPORT FRONT+BACK	x2




## HARDWARE REQUIRED

A		01
---	---	----

B		04
---	---	----

M		08
---	---	----

## TOOLS REQUIRED



# STEP 3


### PARTS REQUIRED

7- CENTRE SUPPORT x1




9- DIVIDING PANEL x1

### HARDWARE REQUIRED

A  01

B  Ø6 x 30mm 05

### TOOLS REQUIRED



Detail 1

# STEP 4

### PARTS REQUIRED




9- DIVIDING PANEL x1

### HARDWARE REQUIRED

H  Ø6 x 8mm 02

C  Right 350mm 01

### TOOLS REQUIRED



Detail 7

# STEP 5

## PARTS REQUIRED





9- DIVIDING PANEL x1

## HARDWARE REQUIRED

C  Left 01  
350mm

H  02  
Ø6 x 8mm

## TOOLS REQUIRED



# STEP 6




## PARTS REQUIRED

10-TOP PANEL x1

## HARDWARE REQUIRED

G  06

## TOOLS REQUIRED




# STEP 7

## PARTS REQUIRED

6- LEFT SIDE PANEL x1





## HARDWARE REQUIRED

A  01


B  04  
Ø6 x 30mm

G  01


## TOOLS REQUIRED



Detail 1



Detail 3



# STEP 8

## PARTS REQUIRED





6- LEFT SIDE PANEL x1

## HARDWARE REQUIRED

C  03  
Left  
350mm

H  06  
Ø6 x 8mm

## TOOLS REQUIRED




Detail 7


# STEP 9


## PARTS REQUIRED

8- RIGHT SIDE PANEL x1





## HARDWARE REQUIRED

A  01


B  04

G  01

## TOOLS REQUIRED



Detail 1



Detail 3

# STEP 10

## PARTS REQUIRED




8 - RIGHT SIDE PANEL x1

## HARDWARE REQUIRED

C  03

H  06

## TOOLS REQUIRED



Detail 7





# STEP 11






### PARTS REQUIRED

1- LEFT LEG	x2
3- RIGHT LEG	x2
4- LEG SUPPORT FRONT & BACK	x2

### HARDWARE REQUIRED

A		01
N		04


### TOOLS REQUIRED





# STEP 12

### PARTS REQUIRED






2- LEG SUPPORT LEFT & RIGHT	x2
-----------------------------	----



### HARDWARE REQUIRED


A		01
N		02

### TOOLS REQUIRED




# STEP 13




## PARTS REQUIRED




## HARDWARE REQUIRED




## TOOLS REQUIRED



Detail 9




Detail 8





# STEP 14

## PARTS REQUIRED




5- BASE PANEL	x1
---------------	----




## HARDWARE REQUIRED



## TOOLS REQUIRED




Detail 9



Detail 10

# STEP 15




## PARTS REQUIRED



## HARDWARE REQUIRED



## TOOLS REQUIRED



# STEP 16


## PARTS REQUIRED

6- LEFT SIDE PANEL	x1
--------------------	----




7- CENTRE SUPPORT	x1
-------------------	----

8- RIGHT SIDE PANEL	x1
---------------------	----


## HARDWARE REQUIRED




## TOOLS REQUIRED



**Detail 9**



**Detail 8**





# STEP 17




## PARTS REQUIRED

9- DIVIDING PANEL	x1
10- TOP PANEL	x1


## HARDWARE REQUIRED

A		01
N		02


## TOOLS REQUIRED



Detail 9




Detail 8






Cam bolt head needs to be in centre



# STEP 18

## PARTS REQUIRED




## HARDWARE REQUIRED


A		01
N		04
R	 Ø4,0 x 50mm	01




Detail 9



Detail 12




Detail 8



Cam bolt head needs to be in centre

# STEP 19

**PARTS REQUIRED**






**HARDWARE REQUIRED**


A		01
---	--	----

N		04
---	--	----


**TOOLS REQUIRED**



Detail 9




Detail 8



# STEP 20

**PARTS REQUIRED**

11- BACK PANEL	x2
----------------	----




**HARDWARE REQUIRED**

E		24
10x10		





Q		04
---	--	----

S		01
456mm		


**TOOLS REQUIRED**



FOR YOUR REFERENCE  
ORDER NUMBER  
SHOULD BE HERE.



Detail 13



Detail 12

# STEP 21



## PARTS REQUIRED

- 12- DRAWER BACK(LARGE) x1
- 13- DRAWER SIDES x6
- 14- DRAWER BACK(SMALL) x2
- 19- DRAWER BACK(MEDIUM) x1
- 22- DRAWER SIDES(LARGE) x2
- 23- DRAWER BASE SUPPORT x2

## HARDWARE REQUIRED

- A  01
- B  Ø6 x 30mm 36

## TOOLS REQUIRED



# STEP 22



## PARTS REQUIRED

- 15- DRAWER FRONT PINE LARGE x1
- 17- DRAWER FRONT(LEFT) x1
- 18- DRAWER FRONT(RIGHT) x1
- 21- CENTRE DRAWER FRONT x1

## HARDWARE REQUIRED

- G  08

## TOOLS REQUIRED



# STEP 23


SEC/SH/12/22/DV1

## PARTS REQUIRED




13- DRAWER SIDES x4

14- DRAWER BACK(SMALL) x2

## HARDWARE REQUIRED

D  04  
Ø4,0 x 40mm

## TOOLS REQUIRED




Detail 14

# STEP 24

## PARTS REQUIRED

17 - DRAWER FRONT(LEFT) x1






## HARDWARE REQUIRED

A  01


F  Ø12mm 02

J  02


## TOOLS REQUIRED



Detail 9




Detail 16



# STEP 25

## PARTS REQUIRED

18 - DRAWER FRONT(RIGHT) x1






## HARDWARE REQUIRED

A 01


F Ø12mm 02

J 02


## TOOLS REQUIRED



Detail 9



Detail 16




Cam bolt head needs to be in centre

# STEP 26

## PARTS REQUIRED

16 - DRAWER BASE x2



X2





## HARDWARE REQUIRED

E 10


## TOOLS REQUIRED



X2




Detail 17






# STEP 27





**PARTS REQUIRED**



**HARDWARE REQUIRED**




**TOOLS REQUIRED**




# STEP 28




**PARTS REQUIRED**



**HARDWARE REQUIRED**



**TOOLS REQUIRED**




# STEP 29

## PARTS REQUIRED



13- DRAWER SIDES x2

19- DRAWER BACK(MEDIUM) x1

## HARDWARE REQUIRED

D  02  
Ø4,0 x 40mm


## TOOLS REQUIRED




# STEP 30

## PARTS REQUIRED

21 - CENTRE DRAWER FRONT x1





## HARDWARE REQUIRED

A  01

F  Ø12mm 02

J  02

## TOOLS REQUIRED




# STEP 31

## PARTS REQUIRED

20- DRAWER BASE(LARGE) x1

23- DRAWER BASE SUPPORT x1






## HARDWARE REQUIRED


A 01

E 08





## TOOLS REQUIRED



Detail 9




Detail 17



# STEP 32

## PARTS REQUIRED



## HARDWARE REQUIRED





C LEFT 01

C RIGHT 01



I 04  
Ø3,0 x 14mm

P 02  
Ø3,5 x 25mm

## TOOLS REQUIRED




Detail 18





Detail 19

# STEP 33




**PARTS REQUIRED**



**HARDWARE REQUIRED**



**TOOLS REQUIRED**



Detail 20


# STEP 34

**PARTS REQUIRED**




22- DRAWER SIDES(LARGE) x2

12- DRAWER BACK(LARGE) x1

**HARDWARE REQUIRED**



**TOOLS REQUIRED**




Detail 15

# STEP 35

## PARTS REQUIRED

15 - DRAWER FRONT PINE(LARGE) x1







## HARDWARE REQUIRED

A 01


F Ø12mm 02

J 02


## TOOLS REQUIRED



Detail 9



Detail 16




# STEP 36

## PARTS REQUIRED

20- DRAWER BASE(LARGE) x1

23- DRAWER BASE SUPPORT x1






## HARDWARE REQUIRED


A 01

E 08




## TOOLS REQUIRED



Detail 9




Detail 17





# STEP 37



**PARTS REQUIRED**



**HARDWARE REQUIRED**




**TOOLS REQUIRED**





# STEP 38




**PARTS REQUIRED**




**HARDWARE REQUIRED**




**TOOLS REQUIRED**



# STEP 39




**PARTS REQUIRED**




**HARDWARE REQUIRED**

**TOOLS REQUIRED**




# STEP 40




**PARTS REQUIRED**



**HARDWARE REQUIRED**



**TOOLS REQUIRED**




## WARNING

**Serious or fatal injuries can occur from furniture tipping over. To prevent the furniture from tipping over we recommend that it is permanently fixed to the wall.**

Wall fixings are not supplied with this product as different wall materials require different types of fixing devices. Please make sure you use fixings suitable for the walls in your home.

# CODY 2 DRAWER BEDSIDE ASSEMBLY INSTRUCTIONS WHITE/PINE EFFECT

XXXXXX



## **IMPORTANT FOR DOMESTIC USE ONLY PLEASE READ BEFORE YOU CONTINUE FURTHER CARE AND MAINTENANCE**

After unpacking this product please keep the original packaging in case it needs to be returned for any reason.

- Please ensure all fittings and parts are present before commencing with assembly.
- Never drag or push products as this could cause damage to the joints making it inferior.
- We strongly recommend that you keep children away from your work area.
- We recommend that you lay a blanket or sheet on the floor to avoid damage to both your floor and the product.
- Assemble this product as close to its final position as possible.
- Do not place this product next to a radiator or in direct sunlight.
- Do not drag or push items across your high gloss furniture as this may cause the surface to scratch
- Wood is a natural product and may expand if subjected to damp and may shrink or crack if subjected to heat. Therefore it is recommended that room temperature is maintained, with no sudden temperature fluctuations.
- Make sure any spillage is wiped off immediately.
- Do not place hot or chilled items directly on to the surface, use a place mat or marking will occur.
- For general cleaning use a soft cotton or micro fibre cloth, and do not use detergents of any kind.
- From time to time it may be necessary to tighten fittings, regular inspections should be carried out.
- Do not place on a wet or damp floor as staining may occur to your floor.






\* Use of power tools to assemble this product will invalidate any claim and could damage this product making it unsafe!!!  
\* Please assemble on a clean soft surface to avoid damage.



\* Please check contents and read the instructions before commencing assembly.  
\* Assemble this product following the enclosed instructions carefully.  
\* Please take care to avoid damaging parts during assembly.

















## PART LIST

### Please Note:







The below parts have all been stamped with the part number/color to help identify them during assembly.

Part Number	Part Code	Part Description	Quantity	Carton
1	S100-103-090-DV1-01	Left Leg	2	1/1
2	S100-103-090-DV1-02	Leg Support Left & Right	2	1/1
3	S100-103-090-DV1-03	Right Leg	2	1/1
4	S100-103-090-DV1-04	Leg Support Front & Back	2	1/1
5	S100-103-090-DV1-05	Base Panel	1	1/1
6	S100-103-090-DV1-06	Left Side Panel	1	1/1
7	S100-103-090-DV1-07	Right Side panel	1	1/1
8	S100-103-090-DV1-08	Top Panel	1	1/1
9	S100-103-090-DV1-09	Back Panel	1	1/1
10	S100-103-090-DV1-10	Drawer Side (Small)	2	1/1
11	S100-103-090-DV1-11	Drawer Back (Small)	1	1/1
12	S100-103-090-DV1-12	Drawer Base	2	1/1
13	S100-103-090-DV1-13	Drawer Side (Large)	2	1/1
14	S100-103-090-DV1-14	Drawer Front White (Small)	1	1/1
15	S100-103-090-DV1-15	Drawer Back (Large)	1	1/1
16	S100-103-090-DV1-16	Drawer Front Pine (Large)	1	1/1

### FITTINGS LIST


<p><b>A</b></p>  <p>Glue (2x)</p>	<p><b>B</b></p>  <p>2/+ Dowel Ø6,0 x 30mm (28x)</p>	<p><b>C</b></p>  <p>Slide 350mm (2x)</p>	<p><b>D</b></p>  <p>1/+ Flat Head Screw Ø4,0 x 40mm (8x)</p>
<p><b>E</b></p>  <p>2/+ Nail 10 x 10 (22x)</p>	<p><b>F</b></p>  <p>1/+ Cam Nut 12mm (4x)</p>	<p><b>G</b></p>  <p>1/+ Cam Bolt (20x)</p>	<p><b>H</b></p>  <p>1/+ Screw Ø 6x8 (8x)</p>
<p><b>I</b></p>  <p>1/+ Flat Head Screw Ø3,0 x 14mm (8x)</p>	<p><b>J</b></p>  <p>2/+ Hole Plugs (4x)</p>	<p><b>K</b></p>  <p>1/+ Flan Head Screw Ø4,0 x 30mm (2x)</p>	<p><b>L</b></p>  <p>1/+ Cam Nut 15mm (16x)</p>
<p><b>M</b></p>  <p>2/+ Dowel Ø8,0 x 30mm (8x)</p>	<p><b>N</b></p>  <p>Handle(2x)</p>		

### TOOLS REQUIRED


	
	
	

### TIPS FOR FITTINGS CAM-LOCKS

WHEN FITTING CAM NUT. ENSURE STARTING POSITION IS CORRECT BEFORE YOU INSERT CONNECTING CAM BOLT TURN CLOCKWISE UNTIL SECURE




**CORRECT**      **WRONG**



**Cam bolt head needs to be in centre**

#### CAMBOLT

Tighten until shoulder in flush with panel. Do not overtighten or undertighten (see example beside)



# STEP 1

## PARTS REQUIRED




1 - LEFT LEG x2

3 - RIGHT LEG x2

## HARDWARE REQUIRED

G  08

## TOOLS REQUIRED



# STEP 2


## PARTS REQUIRED


2- LEG SUPPORT LEFT&RIGHT x2

4- LEG SUPPORT FRONT&BACK x2




## HARDWARE REQUIRED

A  01

B  Ø6 x 30mm 04

M  Ø8 x 30mm 08

## TOOLS REQUIRED



# STEP 3




## PARTS REQUIRED

8 - TOP PANEL x1

## HARDWARE REQUIRED

G  04

## TOOLS REQUIRED




# STEP 4

## PARTS REQUIRED




7- RIGHT SIDE PANEL x1

## HARDWARE REQUIRED

A  01

B  Ø6 x 30mm 04

## TOOLS REQUIRED



# STEP 5

## PARTS REQUIRED




7- RIGHT SIDE PANEL x1

## HARDWARE REQUIRED

C  02  
350mm

H  04  
Ø6 x 8mm

## TOOLS REQUIRED



Detail 7

# STEP 6

## PARTS REQUIRED




6- LEFT SIDE PANEL x1

## HARDWARE REQUIRED

A  01  
Glue

B  04  
Ø6 x 30mm

## TOOLS REQUIRED



Detail 1

# STEP 7

## PARTS REQUIRED





6- Left Side Panel x1

## HARDWARE REQUIRED

C  02  
350mm

H  04  
Ø6 x 8mm

## TOOLS REQUIRED



# STEP 8


## PARTS REQUIRED

1- LEFT LEG x2

3- LEG RIGHT x2






4- LEG SUPPORT FRONT & BACK x2

## HARDWARE REQUIRED

A  01  
Glue

L  04


## TOOLS REQUIRED




# STEP 9

## PARTS REQUIRED

2- SUPPORT LEFT & RIGHT x2






## HARDWARE REQUIRED


A  01

L  02


## TOOLS REQUIRED



Detail 9




Detail 8



Cam bolt head needs to be in centre

# STEP 10

## PARTS REQUIRED






## HARDWARE REQUIRED


A  01

L  02


## TOOLS REQUIRED



Detail 9



Detail 8




Cam bolt head needs to be in centre

# STEP 11


## PARTS REQUIRED

5- BASE PANEL x1






## HARDWARE REQUIRED


A  01

D  Ø4,0 x 40mm 04

## TOOLS REQUIRED




Detail 9



Detail 10

# STEP 12




## PARTS REQUIRED




## HARDWARE REQUIRED

G  04

## TOOLS REQUIRED



Detail 3






# STEP 13

## PARTS REQUIRED




- 6- LEFT SIDE PANEL x1
- 7- RIGHT SIDE PANEL x1




## HARDWARE REQUIRED

- A 01
- L 04


## TOOLS REQUIRED



Detail 9




Detail 8



# STEP 14

## PARTS REQUIRED




- 8 - TOP PANEL x1




## HARDWARE REQUIRED

- A 01
- L 04


## TOOLS REQUIRED



Detail 9




Detail 8




# STEP 15

## PARTS REQUIRED



9 - BACK PANEL x1




## HARDWARE REQUIRED

E  12  
10x10

## TOOLS REQUIRED



FOR YOUR REFERENCE  
ORDER NUMBER  
SHOULD BE HERE.




# STEP 16


## PARTS REQUIRED

13- DRAWER SIDE (LARGE) x2




15- DRAWER BACK (LARGE) x1

## HARDWARE REQUIRED

A  01

B  08  
Ø6 x 30mm

## TOOLS REQUIRED



Detail 1

# STEP 17




## PARTS REQUIRED

16- DRAWER FRONT PINE x1

## HARDWARE REQUIRED

G  02

## TOOLS REQUIRED




# STEP 18

## PARTS REQUIRED

13- DRAWER SIDE (LARGE) x2





15- DRAWER BACK (LARGE) x1

## HARDWARE REQUIRED

D  02  
Ø4,0 x 40mm

A  01


## TOOLS REQUIRED






# STEP 19

## PARTS REQUIRED





16 - DRAWER FRONT PINE x1




## HARDWARE REQUIRED

- A  01
- F  Ø12mm 02
- J  02


## TOOLS REQUIRED



Detail 9



Detail 15




Cam bolt head needs to be in centre


# STEP 20

## PARTS REQUIRED




12 - DRAWER BASE x1




## HARDWARE REQUIRED

E  05

## TOOLS REQUIRED




Detail 16





# STEP 21





## PARTS REQUIRED



## HARDWARE REQUIRED




## TOOLS REQUIRED





Detail 17

# STEP 22




## PARTS REQUIRED



## HARDWARE REQUIRED



## TOOLS REQUIRED



Detail 19

# STEP 23


## PARTS REQUIRED

10- DRAWER SIDE (SMALL) x2




11- DRAWER BACK (SMALL) x1

## HARDWARE REQUIRED

A  01

B  Ø6 x 30mm 04

## TOOLS REQUIRED



# STEP 24




## PARTS REQUIRED

14- DRAWER FRONT WHITE x1

## HARDWARE REQUIRED

G  02

## TOOLS REQUIRED



# STEP 25


## PARTS REQUIRED

10- DRAWER SIDE (SMALL) x2




11- DRAWER BACK (SMALL) x1

## HARDWARE REQUIRED


A  01

D  Ø4,0 x 40mm 02

## TOOLS REQUIRED



Detail 9




Detail 14


# STEP 26


## PARTS REQUIRED

16 - DRAWER FRONT PINE x1






## HARDWARE REQUIRED

A  01


F  Ø12mm 02

J  02


## TOOLS REQUIRED



Detail 9




Detail 15




# STEP 27

## PARTS REQUIRED





12 - DRAWER BASE x1



## HARDWARE REQUIRED


E  05

## TOOLS REQUIRED






# STEP 28




## PARTS REQUIRED



## HARDWARE REQUIRED

C  LEFT 01  
 C  RIGHT 01  
 I  Ø3,0 x 14mm 04


## TOOLS REQUIRED







# STEP 29




**PARTS REQUIRED**



**HARDWARE REQUIRED**







**TOOLS REQUIRED**




**Detail 19**

# STEP 30

**PARTS REQUIRED**



# CODY 2 DOOR 4 DRAWER STORAGE UNIT ASSEMBLY INSTRUCTIONS WHITE/PINE EFFECT



## **IMPORTANT FOR DOMESTIC USE ONLY**

**PLEASE READ BEFORE YOU CONTINUE FURTHER**

## **CARE AND MAINTENANCE**

After unpacking this product please keep the original packaging in case it needs to be returned for any reason.




- Please ensure all fittings and parts are present before commencing with assembly.
- Never drag or push products as this could cause damage to the joints making it inferior.
- We strongly recommend that you keep children away from your work area.
- We recommend that you lay a blanket or sheet on the floor to avoid damage to both your floor and the product.
- Assemble this product as close to its final position as possible.
- Do not place this product next to a radiator or in direct sunlight.
- Do not drag or push items across your high gloss furniture as this may cause the surface to scratch
- Wood is a natural product and may expand if subjected to damp and may shrink or crack if subjected to heat. Therefore it is recommended that room temperature is maintained, with no sudden temperature fluctuations.
- Make sure any spillage is wiped off immediately.
- Do not place hot or chilled items directly on to the surface, use a place mat or marking will occur.
- For general cleaning use a soft cotton or micro fibre cloth, and do not use detergents of any kind.
- From time to time it may be necessary to tighten fittings, regular inspections should be carried out.
- Do not place on a wet or damp floor as staining may occur to your floor.



- \* Use of power tools to assemble this product will invalidate any claim and could damage this product making it unsafe!!!
- \* Please assemble on a clean soft surface to avoid damage.



- \* Please check contents and read the instructions before commencing assembly.
- \* Assemble this product following the enclosed instructions carefully.
- \* Please take care to avoid damaging parts during assembly.




























## PART LIST

### Please Note:

The below parts have all been stamped with the part number/color to help identify them during assembly.



Part Number	Part Code	Part Description	Quantity	Carton
1	S100-120-021-DV1-01	Left Leg	2	2/2
2	S100-120-021-DV1-02	Leg Support Left & Right	2	1/2
3	S100-120-021-DV1-03	Right Leg	2	2/2
4	S100-120-021-DV1-04	Leg Support Front & Back	2	1/2
5	S100-120-021-DV1-05	Centre Foot	1	2/2
6	S100-120-021-DV1-06	Base Panel	1	1/2
7	S100-120-021-DV1-07	Left Side Panel	1	1/2
8	S100-120-021-DV1-08	Division Panel	1	1/2
9	S100-120-021-DV1-09	Shelf	1	2/2
10	S100-120-021-DV1-10	Right Side Panel	1	1/2
11	S100-120-021-DV1-11	Left Back Panel	1	2/2
12	S100-120-021-DV1-12	Drawer Back (Large)	1	2/2
13	S100-120-021-DV1-13	Top Panel	1	1/2
14	S100-120-021-DV1-14	Right Back Panel	2	2/2
15	S100-120-021-DV1-15	Drawer Back (Small)	3	1/2
16	S100-120-021-DV1-16	Drawer Base	3	2/2
17	S100-120-021-DV1-17	Drawer Front White (Small)	2	1/2
18	S100-120-021-DV1-18	Drawer Front Pine (Small)	1	1/2
19	S100-120-021-DV1-19	Drawer Front Pine (Large)	1	1/2
20	S100-120-021-DV1-20	Drawer Base	1	2/2
21	S100-120-021-DV1-21	Left Door	1	2/2
22	S100-120-021-DV1-22	Drawer Sides	8	2/2
23	S100-120-021-DV1-23	Drawer Base Support	1	2/2
24	S100-120-021-DV1-24	Right Door	1	2/2

# FITTINGS LIST


<b>A</b>  Glue (3x)	<b>B</b>  Dowel Ø6,0 x 30mm (50x) 2/+	<b>C</b>  Slide 350mm (4x)	<b>D</b>  Flat Head Screw Ø4,0 x 40mm (14x) 1/+
<b>E</b>  Nail 10 x 10 (52x) 5/+	<b>F</b>  Cam Nut 12mm (12x) 1/+	<b>G</b>  Cam Bolt (32x) 1/+	<b>H</b>  Screw Ø 6x8 (16x) 1/+
<b>I</b>  Flat Head Screw Ø3,0 x 14mm (16x) 1/+	<b>J</b>  Hole Plugs (10x) 2/+	<b>K</b>  Washer 02 (2X) Anti-tip strap 01	
<b>L</b>  Flan Head Screw Ø4,0 x 30mm (6x) 1/+	<b>M</b>  Pan Head Screw Ø4,0 x 14mm (16x) 1/+	<b>N</b>  Dowel Ø8,0 x 30mm (10x) 2/+	<b>O</b>  Flan Head Screw Ø3,5 x 12mm (4x) 1/+
<b>P</b>  Flat Head Screw Ø3,5 x 25mm (2x) 1/+	<b>Q</b>  Back Panel Bracket (5x) 1/+	<b>R</b>  Centre Hinge (2x)	<b>S</b>  End Hinge (2x)
<b>T</b>  Flat Head Screw Ø7 x 40mm (1x)	<b>U</b>  Hinge Plate (4x)	<b>V</b>  Door Stop (2x)	<b>W</b>  Cam Nut 15mm (20x) 1/+
<b>X</b>  Plastic profile 626mm (1x)		<b>Y</b>  Handle(6x)	

## TIPS FOR FITTINGS CAM-LOCKS

WHEN FITTING CAM NUT. ENSURE STARTING POSITION IS CORRECT BEFORE YOU INSERT CONNECTING CAM BOLT TURN CLOCKWISE UNTIL SECURE




## TOOLS REQUIRED



## CAMBOLT

Tighten until shoulder in flush with panel. Do not overtighten or undertighten (see example beside)




# STEP 1




## PARTS REQUIRED

- 1 - LEFT LEG x2
- 3 - RIGHT LEG x2

## HARDWARE REQUIRED

- G  08

## TOOLS REQUIRED






# STEP 2





## PARTS REQUIRED

- 2- LEG SUPPORT LEFT & RIGHT x2
- 4- LEG SUPPORT FRONT & BACK x2

## HARDWARE REQUIRED

- A  01
- B  Ø6 x 30mm 04
- N  Ø8 x 30mm 08

## TOOLS REQUIRED



**Detail 1**

**Detail 2**


# STEP 3

## PARTS REQUIRED


9 - SHELF x1

## HARDWARE REQUIRED



A  01

B  Ø6 x 30mm 04

O  Ø3,5 x 12mm 02

V  01

## TOOLS REQUIRED




# STEP 4


## PARTS REQUIRED

13 - TOP PANEL x1



## HARDWARE REQUIRED

G  06

O  Ø3,5 x 12mm 02

V  01

## TOOLS REQUIRED



# STEP 5

## PARTS REQUIRED




7- LEFT SIDE PANEL x1

## HARDWARE REQUIRED

A  01

B  04

## TOOLS REQUIRED



# STEP 6

## PARTS REQUIRED




7- LEFT SIDE PANEL x1

## HARDWARE REQUIRED

C  03

H  06

## TOOLS REQUIRED




# STEP 7

## PARTS REQUIRED




8- DIVISION PANEL x1

## HARDWARE REQUIRED

A  01

B  Ø6 x 30mm 04

## TOOLS REQUIRED



# STEP 8

## PARTS REQUIRED




8- DIVISION PANEL x1

## HARDWARE REQUIRED

C  350mm 03

H  Ø6 x 8mm 06

## TOOLS REQUIRED










# STEP 9





## PARTS REQUIRED

8 - DIVISION PANEL x1



## HARDWARE REQUIRED

C		01
G		02
H		02
M		04
U		02


## TOOLS REQUIRED



Detail 3



Detail 6






Detail 7

# STEP 10





## PARTS REQUIRED

10- RIGHT SIDE PANEL x1


## HARDWARE REQUIRED

A		01
B		04
G		02


## TOOLS REQUIRED



Detail 1



Detail 3






# STEP 11

## PARTS REQUIRED


10 - RIGHT SIDE PANEL x1

C	Right 350mm	01
H	Ø6 x 8mm	02
M	Ø4.0 x 14mm	04
U		02

## TOOLS REQUIRED



Detail 7



Detail 6

# STEP 12

## PARTS REQUIRED

1 - LEFT LEG x2




3 - RIGHT LEG x2

4 - LEG SUPPORT FRONT & BACKx2


## HARDWARE REQUIRED

A	Glue	01
W		04


## TOOLS REQUIRED



Detail 9



Detail 8




Cam bolt head needs to be in centre

# STEP 13

## PARTS REQUIRED

2 - LEG SUPPORT LEFT & RIGHTx2






## HARDWARE REQUIRED


A  01

W  02


## TOOLS REQUIRED



Detail 9




Detail 8




Cam bolt head needs to be in centre

# STEP 14

## PARTS REQUIRED






## HARDWARE REQUIRED


A  01

W  02


## TOOLS REQUIRED



Detail 8



Cam bolt head needs to be in centre




Detail 9


# STEP 15


## PARTS REQUIRED

6 - BASE PANEL x1






## HARDWARE REQUIRED


A  01

D  06  
Ø4,0 x 40mm

## TOOLS REQUIRED




Detail 9




Detail 10

# STEP 16




## PARTS REQUIRED




## HARDWARE REQUIRED

G  06

## TOOLS REQUIRED




Detail 3




# STEP 17

### PARTS REQUIRED




5 - CENTRE FOOT x1



### HARDWARE REQUIRED

T  01  
Ø7 x 40mm

### TOOLS REQUIRED



Detail 18

# STEP 18

### PARTS REQUIRED

8 - DIVISION PANEL x1

9 - SHELF x1




10 - RIGHT SIDE PANEL x1

### HARDWARE REQUIRED


A  01

F  Ø12mm 04


### TOOLS REQUIRED



Detail 9




Detail 11




# STEP 19

## PARTS REQUIRED






## HARDWARE REQUIRED


A		01
---	---	----

W		04
---	---	----


## TOOLS REQUIRED



Detail 9



Detail 8




Cam bolt head needs to be in centre


# STEP 20

## PARTS REQUIRED

7- LEFT SIDE PANEL	x1
--------------------	----






## HARDWARE REQUIRED


A		01
---	---	----

W		02
---	---	----


## TOOLS REQUIRED



Detail 9



Detail 8




Cam bolt head needs to be in centre

# STEP 21

## PARTS REQUIRED




13 - TOP PANEL x1




## HARDWARE REQUIRED

A		01
W		06
J		02


## TOOLS REQUIRED



Detail 9



Detail 8




Cam bolt head needs to be in centre

# STEP 22

## PARTS REQUIRED

11- BACK PANEL x1



14- BACK PANEL x2





## HARDWARE REQUIRED

E		29
Q		05
X		01


## TOOLS REQUIRED



FOR YOUR REFERENCE ORDER NUMBER SHOULD BE HERE.



Detail 13





Detail 12

# STEP 23




## PARTS REQUIRED

- 12- DRAWER BACK (LARGE) x1
- 15- DRAWER BACK (SMALL) x3
- 22- DRAWER SIDES x8
- 23- DRAWER BASE SUPPORT x1

## HARDWARE REQUIRED

- A  01
- B  Ø6 x 30mm 34

## TOOLS REQUIRED




# STEP 24



## PARTS REQUIRED

- 17- DRAWER FRONT WHITE (SMALL) x2
- 18- DRAWER FRONT PINE (SMALL) x1
- 19- DRAWER FRONT PINE (LARGE) x1

## HARDWARE REQUIRED

- G  08

## TOOLS REQUIRED






# STEP 25

## PARTS REQUIRED




22- DRAWER SIDES x6

15- DRAWER BACK (SMALL) x3

## HARDWARE REQUIRED

D  06  
Ø4,0 x 40mm


## TOOLS REQUIRED




# STEP 26

## PARTS REQUIRED

17- DRAWER FRONT WHITE (SMALL) x2






## HARDWARE REQUIRED

A  01


F  Ø12mm 04

J  04


## TOOLS REQUIRED



Detail 9




Detail 16



# STEP 27

## PARTS REQUIRED

18- DRAWER FRONT PINE (SMALL) x1







## HARDWARE REQUIRED

A 01


F Ø12mm 02

J 02


## TOOLS REQUIRED



Detail 9



Detail 16




# STEP 28

## PARTS REQUIRED

16 - DRAWER BASE x2





X2




## HARDWARE REQUIRED

E 10

## TOOLS REQUIRED




Detail 17



# STEP 29

## PARTS REQUIRED





16 - DRAWER BASE x1



## HARDWARE REQUIRED


E  05

## TOOLS REQUIRED



# STEP 30


## PARTS REQUIRED







## HARDWARE REQUIRED

C LEFT  02

C RIGHT  02

I  08  
Ø3.0 x 14mm


## TOOLS REQUIRED




Detail 19

# STEP 31





**PARTS REQUIRED**



**HARDWARE REQUIRED**


- C LEFT 01
- C RIGHT 01
- I  04  
Ø3,0 x 14mm

**TOOLS REQUIRED**





# STEP 32




**PARTS REQUIRED**



**HARDWARE REQUIRED**

- Y  02
- L  02  
Ø4,0 x 30mm


**TOOLS REQUIRED**




Detail 20

# STEP 33




**PARTS REQUIRED**



**HARDWARE REQUIRED**




**TOOLS REQUIRED**




Detail 20

# STEP 34




**PARTS REQUIRED**



**HARDWARE REQUIRED**



**TOOLS REQUIRED**




Detail 15

# STEP 35

## PARTS REQUIRED

19- DRAWER FRONT PINE (LARGE) x1







## HARDWARE REQUIRED

A 01


F Ø12mm 02

J 02


## TOOLS REQUIRED



Detail 9



Detail 16




# STEP 36

## PARTS REQUIRED

20- DRAWER BASE x1

23- DRAWER BASE SUPPORT x1






## HARDWARE REQUIRED


A 01

E 08





## TOOLS REQUIRED



Detail 9




Detail 17





# STEP 37



**PARTS REQUIRED**



**HARDWARE REQUIRED**




**TOOLS REQUIRED**




# STEP 38



**PARTS REQUIRED**



**HARDWARE REQUIRED**




**TOOLS REQUIRED**




# STEP 39

PARTS REQUIRED



HARDWARE REQUIRED

TOOLS REQUIRED





# STEP 40

PARTS REQUIRED




21 - LEFT DOOR x1

HARDWARE REQUIRED

M  04  
Ø4,0 x 14mm

S  02

TOOLS REQUIRED



Detail 22




# STEP 41

## PARTS REQUIRED




24 - RIGHT DOOR x1

## HARDWARE REQUIRED

M  04  
Ø4.0 x 14mm

R  02


## TOOLS REQUIRED




# STEP 42

## PARTS REQUIRED

24- RIGHT DOOR x1








## HARDWARE REQUIRED


L  01  
Ø4.0 x 30mm

Y  01

## TOOLS REQUIRED




# STEP 43



**PARTS REQUIRED**

21- LEFT DOOR x1






**HARDWARE REQUIRED**


L 01  
Ø4,0 x 30mm

Y 01

**TOOLS REQUIRED**




Detail 23



Detail 24

# STEP 44






**PARTS REQUIRED**



**HARDWARE REQUIRED**

K 02

**TOOLS REQUIRED**



## WARNING

**Serious or fatal injuries can occur from furniture tipping over. To prevent the furniture from tipping over we recommend that it is permanently fixed to the wall.**

Wall fixings are not supplied with this product as different wall materials require different types of fixing devices. Please make sure you use fixings suitable for the walls in your home.




# CODY 1 DRAWER HOUSE BED

## ASSEMBLY INSTRUCTIONS

### WHITE/PINE EFFECT

XXXXX





### **IMPORTANT FOR DOMESTIC USE ONLY**

**PLEASE READ BEFORE YOU CONTINUE FURTHER**

## **CARE AND MAINTENANCE**

After unpacking this product please keep the original packaging in case it needs to be returned for any reason.

- Please ensure all fittings and parts are present before commencing with assembly.
- Never drag or push products as this could cause damage to the joints making it inferior.
- We strongly recommend that you keep children away from your work area.
- We recommend that you lay a blanket or sheet on the floor to avoid damage to both your floor and the product.
- Assemble this product as close to its final position as possible.
- Do not place this product next to a radiator or in direct sunlight.
- Do not drag or push items across your high gloss furniture as this may cause the surface to scratch
- Wood is a natural product and may expand if subjected to damp and may shrink or crack if subjected to heat. Therefore it is recommended that room temperature is maintained, with no sudden temperature fluctuations.
- Make sure any spillage is wiped off immediately.
- Do not place hot or chilled items directly on to the surface, use a place mat or marking will occur.
- For general cleaning use a soft cotton or micro fibre cloth, and do not use detergents of any kind.
- From time to time it may be necessary to tighten fittings, regular inspections should be carried out.
- Do not place on a wet or damp floor as staining may occur to your floor.
























**PARTS LIST**

***Please Note:***

The below parts have all been stamped with the part number to help identify them during assembly.


Part Number	Part Code	Part Description	Quantity	Carton
1	S200-201-072-DV1-01	Right Side Of Seat	1	1/3
2	S200-201-072-DV1-02	Left Side Of Seat	1	1/3
3	S200-201-072-DV1-03	Seat Shelf	1	1/3
4	S200-201-072-DV1-04	Centre Divider	1	1/3
5	S200-201-072-DV1-05	Footboard	1	1/3
6	S200-201-072-DV1-06	Drawer Stop	2	2/3
7	S200-201-072-DV1-07	Lower Crossbar	1	3/3
8	S200-201-072-DV1-08	Right Side Rail	1	3/3
9	S200-201-072-DV1-09	Left Side Rail	1	3/3
10	S200-201-072-DV1-10	Mattress Base	3	1/3
11	S200-201-072-DV1-11	Right Side Of The House	1	1/3
12	S200-201-072-DV1-12	Left Side Of The House	1	1/3
13	S200-201-072-DV1-13	Headboard	1	1/3
14	S200-201-072-DV1-14	Left Roof Of The House	1	1/3
15	S200-201-072-DV1-15	Right Side Of The House	1	1/3
16	S200-201-072-DV1-16	Upper Crossbar	1	3/3
17	S200-201-072-DV1-17	Drawer Front	1	3/3
18	S200-201-072-DV1-18	Drawer Crossbar	2	2/3
19	S200-201-072-DV1-19	Right Drawer Side	1	2/3
20	S200-201-072-DV1-20	Drawer Botom	2	2/3
21	S200-201-072-DV1-21	Drawer Divider	1	3/3
22	S200-201-072-DV1-22	Left Drawer Side	1	3/3
23	S200-201-072-DV1-23	Drawer Back	1	3/3
24	S200-201-072-DV1-24	Vertical Drawer Stop	2	3/3

# FITTINGS LIST


<p><b>A</b></p>  <p>Glue (3x)</p>	<p><b>B</b></p>  <p>2/+ Dowel Ø6,0 x 30mm (19x)</p>	<p><b>C</b></p>  <p>2/+ Cam Nut 15mm (13x)</p>	<p><b>D</b></p>  <p>1/+ Flat Head Screw Ø4,0 x 40mm (5x)</p>
<p><b>E</b></p>  <p>Drawer caster (4x)</p>	<p><b>F</b></p>  <p>1/+ Dowel Ø8,0 x 20mm (2x)</p>	<p><b>G</b></p>  <p>2/+ Cam Bolt (17x)</p>	<p><b>H</b></p>  <p>2/+ Pan Head Screw Ø3,5 x 14mm (16x)</p>
<p><b>I</b></p>  <p>1/+ Cam Nut 12mm (4x)</p>	<p><b>J</b></p>  <p>2/+ Hole Plugs White (13x)</p>	<p><b>K</b></p>  <p>1/+ Structural Screw Ø7 x 60mm (8x)</p>	<p><b>L</b></p>  <p>2/+ Flat Head Screw Ø3,5 x 30mm (18x)</p>
<p><b>M</b></p>  <p>2/+ Sliding Foot 15 x 15mm (11x)</p>	<p><b>N</b></p>  <p>2/+ Dowel Ø8,0 x 30mm (30x)</p>	<p><b>O</b></p>  <p>2/+ Nail 10x10 mm (11x)</p>	<p><b>P</b></p>  <p>1/+ Flat Head Screw Ø3,5 x 25mm (7x)</p>
<p><b>Q</b></p>  <p>1/+ Flat Head Screw Ø4,0 x 50mm (11x)</p>	<p><b>R</b></p>  <p>1/+ Hole Plugs (Ivory) (4x)</p>	<p><b>S</b></p>  <p>1/+ Flat Head Screw Ø3,5 x 20mm (8x)</p>	<p><b>T</b></p>  <p>Allen key (1x)</p>
<p><b>U</b></p>  <p>Spacer (2x)</p>			

## TIPS FOR FITTINGS CAM-LOCKS

WHEN FITTING CAM NUT. ENSURE STARTING POSITION IS CORRECT BEFORE YOU INSERT CONNECTING CAM BOLT TURN CLOCKWISE UNTIL SECURE




**CORRECT**      **WRONG**



**Cam bolt head needs to be in centre**

### CAMBOLT

Tighten until shoulder in flush with panel. Do not overtighten or undertighten (see example beside)






**Shoulder**      **Panel**      **Panel**

# STEP 1





## PARTS REQUIRED

6 - DRAWER STOP	x2
8 - RIGHT SIDE RAIL	x1
9 - LEFT SIDE RAIL	x1

## HARDWARE REQUIRED

A		01
F		02
N		06

## TOOLS REQUIRED





# STEP 2





## PARTS REQUIRED

5 - FOOTBOARD	x1
6 - DRAWER STOP	x1

## HARDWARE REQUIRED

A		01
D		01

## TOOLS REQUIRED





# STEP 3



## PARTS REQUIRED

5 - FOOTBOARD	x1
13 - HEADBOARD	x1

## HARDWARE REQUIRED

M		04
O		04

## TOOLS REQUIRED






# STEP 4



## PARTS REQUIRED

6- DRAWER STOP	x1
7- LOWER CROSSBAR	x1
16- UPPER CROSSBAR	x1

## HARDWARE REQUIRED

A		01
D	 Ø4,0 x 40mm	01
N	 Ø8 x 30mm	06

## TOOLS REQUIRED





# STEP 5

## PARTS REQUIRED

12 - LEFT SIDE OF THE HOUSE x1

## HARDWARE REQUIRED





A  01

B  03  
Ø6 x 30mm

M  02

O  02

## TOOLS REQUIRED





# STEP 6

## PARTS REQUIRED


11 - RIGHT SIDE OF THE HOUSE x1

## HARDWARE REQUIRED




A  01

B  03  
Ø6 x 30mm

M  02

O  02

## TOOLS REQUIRED




# STEP 7

### PARTS REQUIRED


14-LEFT ROOF OF THE HOUSE x1

15-RIGHT ROOF OF THE HOUSE x1




### HARDWARE REQUIRED

A  01


B  Ø6 x 30mm 02

G  04


### TOOLS REQUIRED



Detail 7



Detail 28




# STEP 8


### PARTS REQUIRED

14-LEFT ROOF OF THE HOUSE x1



15-RIGHT ROOF OF THE HOUSE x1

### HARDWARE REQUIRED


A  01

Q  Ø4,0 x 50mm 03


### TOOLS REQUIRED



PLEASE NOTE PRE-DRILLED HOLES.



Detail 29








Detail 4

# STEP 9




## PARTS REQUIRED

- 1 - RIGHT SIDE OF SEAT x1
- 2 - LEFT SIDE OF SEAT x1

## HARDWARE REQUIRED

- A  01
- B  04
- G  04
- M  02
- O  02

## TOOLS REQUIRED






# STEP 10




## PARTS REQUIRED

- 4 - CENTRE DIVIDER x1

## HARDWARE REQUIRED

- B  03
- M  01
- O  01

## TOOLS REQUIRED




# STEP 11

## PARTS REQUIRED

3 - SEAT SHELF x1






## HARDWARE REQUIRED

A  01

B  Ø6 x 30mm 04

G  02

## TOOLS REQUIRED



# STEP 12


## PARTS REQUIRED

5 - FOOTBOARD x1

8 - RIGHT SIDE RAIL x1





9 - LEFT SIDE RAIL x1

## HARDWARE REQUIRED

A  01

K  Ø7 x 60mm 04


## TOOLS REQUIRED




# STEP 13

## PARTS REQUIRED

13 - HEADBOARD x1






## HARDWARE REQUIRED


A  01

K  Ø7 x 60mm 04

## TOOLS REQUIRED



Detail 4




Detail 8

# STEP 14


## PARTS REQUIRED

12-LEFT SIDE OF THE HOUSE x1






## HARDWARE REQUIRED


A  01

P  Ø3,5 x 25mm 02

## TOOLS REQUIRED



Detail 4




Detail 9

# STEP 15

## PARTS REQUIRED




7-LOWER CROSSBAR	x1
16 - UPPER CROSSBAR	x1




## HARDWARE REQUIRED

A	Glue	01
Q	Ø4 x 50mm	04

## TOOLS REQUIRED



Detail 4




Detail 11

# STEP 16

## PARTS REQUIRED




11-RIGHT SIDE OF THE HOUSE x1
-------------------------------




## HARDWARE REQUIRED

A	Glue	01
P	Ø3,5 x 25mm	02
Q	Ø4 x 50mm	04


## TOOLS REQUIRED



Detail 11




Detail 4



Detail 13

# STEP 17




**PARTS REQUIRED**




**HARDWARE REQUIRED**

A		01
I	Ø12mm	04
R		04


**TOOLS REQUIRED**



Detail 4



Detail 14



# STEP 18




**PARTS REQUIRED**

3 - SEAT SHELF	x1
4 - CENTRE DIVIDER	x1


**HARDWARE REQUIRED**

A		01
C		02
J		02

**TOOLS REQUIRED**



Detail 4




Detail 25

# STEP 19

## PARTS REQUIRED

1 - RIGHT SIDE OF SEAT x1

2 - LEFT SIDE OF SEAT x1






## HARDWARE REQUIRED

A  01


C  04

J  04


## TOOLS REQUIRED



Detail 4




Detail 15



# STEP 20




## PARTS REQUIRED



## HARDWARE REQUIRED

G  04

## TOOLS REQUIRED




Detail 16




# STEP 21




**PARTS REQUIRED**




**HARDWARE REQUIRED**




**TOOLS REQUIRED**



Detail 4




Detail 17




# STEP 22




**PARTS REQUIRED**



**HARDWARE REQUIRED**



**TOOLS REQUIRED**



Detail 17

# STEP 23


## PARTS REQUIRED

18 - DRAWER CROSSBAR	x2
19 - RIGHT DRAWER SIDE	x1
21 - DRAWER DIVIDER	x1
22 - LEFT DRAWER SIDE	x1
23 - DRAWER BACK	x1

## HARDWARE REQUIRED



## TOOLS REQUIRED




# STEP 24




## PARTS REQUIRED

17-DRAWER FRONT	x1
-----------------	----

## HARDWARE REQUIRED



## TOOLS REQUIRED






# STEP 25



## PARTS REQUIRED

17 - DRAWER FRONT	x1
19 - RIGHT DRAWER SIDE	x1
21 - DRAWER DIVIDER	x1
22 - LEFT DRAWER SIDE	x1

## HARDWARE REQUIRED

A		01
C		03
J		03


## TOOLS REQUIRED



# STEP 26


## PARTS REQUIRED

20 - DRAWER BOTTOM	x2
--------------------	----



## HARDWARE REQUIRED

## TOOLS REQUIRED



# STEP 27



## PARTS REQUIRED

18-DRAWER CROSSBAR X2

## HARDWARE REQUIRED

A  01

## TOOLS REQUIRED




Detail 4


# STEP 28


## PARTS REQUIRED

23 - DRAWER BACK x1





## HARDWARE REQUIRED


A  01

D  Ø4 x 40mm 03

## TOOLS REQUIRED




Detail 4




Detail 20

# STEP 29





**PARTS REQUIRED**



**HARDWARE REQUIRED**




**TOOLS REQUIRED**




# STEP 30

**PARTS REQUIRED**





24 - VERTICAL DRAWER STOP X2



**HARDWARE REQUIRED**



**TOOLS REQUIRED**




THE DRAWER CAN BE  
ADD ON BOTH SIDES  
(RIGHT OR LEFT)


# STEP 31

## PARTS REQUIRED




10 - MATTRESS BASE X2



## HARDWARE REQUIRED

L  12  
Ø3,5 x 30mm

## TOOLS REQUIRED




Detail 25


# STEP 32


## PARTS REQUIRED

10 - MATTRESS BASE X1





## HARDWARE REQUIRED


L  06  
Ø3,5 x 30mm

U  02  
Spacer

## TOOLS REQUIRED



**Please fix the first slats adjacent to the headboard and footboard and work towards the middle of the bed using the spacer (U) as shown to ensure correct spacing. Fix all the slats to one siderail first then push the second siderail tight against the slats and fix.**



Detail 26